











Machine	Explode	Code	Description
CW197 - Polar Upright Gastro Display Fridge 600Ltr	1	AB948	Front Panel Hinge
CW197 - Polar Upright Gastro Display Fridge 600Ltr	2	AH322	Front Panel
CW197 - Polar Upright Gastro Display Fridge 600Ltr	3	AB352	Lock & Key
CW197 - Polar Upright Gastro Display Fridge 600Ltr	4	AB363	Thermostat
CW197 - Polar Upright Gastro Display Fridge 600Ltr	5	AB308	Main Switch
CW197 - Polar Upright Gastro Display Fridge 600Ltr	6	AB888	Door Switch
CW197 - Polar Upright Gastro Display Fridge 600Ltr	7	AH314	Up Hinge Right
CW197 - Polar Upright Gastro Display Fridge 600Ltr	7	AH313	Up Hinge Left
CW197 - Polar Upright Gastro Display Fridge 600Ltr	8	AB346	Door Spring
CW197 - Polar Upright Gastro Display Fridge 600Ltr	9		Door
CW197 - Polar Upright Gastro Display Fridge 600Ltr	10	AH319	LED Transformer
CW197 - Polar Upright Gastro Display Fridge 600Ltr	11	AH316	Down Hinge Axis Jacket
CW197 - Polar Upright Gastro Display Fridge 600Ltr	12		Support
CW197 - Polar Upright Gastro Display Fridge 600Ltr	13	AB982	Water Box
CW197 - Polar Upright Gastro Display Fridge 600Ltr	14		Water Pan Guide Right
CW197 - Polar Upright Gastro Display Fridge 600Ltr	14A		Water Pan Guide Left
CW197 - Polar Upright Gastro Display Fridge 600Ltr	15	AE824	Standard Castor
CW197 - Polar Upright Gastro Display Fridge 600Ltr	15		Braked Castor
CW197 - Polar Upright Gastro Display Fridge 600Ltr	16	AA634	Drain Pipe Nut
CW197 - Polar Upright Gastro Display Fridge 600Ltr	17	AB356	Down Hinge Axis
CW197 - Polar Upright Gastro Display Fridge 600Ltr	18	AH320	Down Hinge
CW197 - Polar Upright Gastro Display Fridge 600Ltr	19	AA637	Drain Pipe
CW197 - Polar Upright Gastro Display Fridge 600Ltr	20	AA638	Drain Pipe Cover
CW197 - Polar Upright Gastro Display Fridge 600Ltr	21		Body
CW197 - Polar Upright Gastro Display Fridge 600Ltr	22	AJ527	Guide Right
CW197 - Polar Upright Gastro Display Fridge 600Ltr	22A		Guide Left
CW197 - Polar Upright Gastro Display Fridge 600Ltr	23	AB411	Shelf
CW197 - Polar Upright Gastro Display Fridge 600Ltr	26	AB953	Probe Padding
CW197 - Polar Upright Gastro Display Fridge 600Ltr	27	AA639	Sensor Fixed Clip
CW197 - Polar Upright Gastro Display Fridge 600Ltr	28	AC614	Sensor
CW197 - Polar Upright Gastro Display Fridge 600Ltr	29		Circle Fan Cover
CW197 - Polar Upright Gastro Display Fridge 600Ltr	30	AB339	Circle Fan
CW197 - Polar Upright Gastro Display Fridge 600Ltr	31	AB916	Screen Filter
CW197 - Polar Upright Gastro Display Fridge 600Ltr	32	AH302	Unit Board
CW197 - Polar Upright Gastro Display Fridge 600Ltr	33	AB850	Basket Guard Grilles
CW197 - Polar Upright Gastro Display Fridge 600Ltr	34		Discharge Tube
CW197 - Polar Upright Gastro Display Fridge 600Ltr	37	AG554	Plug
CW197 - Polar Upright Gastro Display Fridge 600Ltr	38	AH303	Suction Pipe
CW197 - Polar Upright Gastro Display Fridge 600Ltr	40	AG014	Compressor(R600a)
CW197 - Polar Upright Gastro Display Fridge 600Ltr	41		Condenser Fan & Blade
CW197 - Polar Upright Gastro Display Fridge 600Ltr	42	AB869	Condenser
CW197 - Polar Upright Gastro Display Fridge 600Ltr	44	AB120	Filter Drier
CW197 - Polar Upright Gastro Display Fridge 600Ltr	45	AH312	Front Panel Fixed Clip
CW197 - Polar Upright Gastro Display Fridge 600Ltr	46	AH317	LED Lamp Right
CW197 - Polar Upright Gastro Display Fridge 600Ltr	47	AH318	LED Lamp Left
CW197 - Polar Upright Gastro Display Fridge 600Ltr	48	AH308	Floor Protector Shelf
CW197 - Polar Upright Gastro Display Fridge 600Ltr	49		Door Seal

CW197 - Polar Upright Gastro Display Fridge 600Ltr	50		Wall Ring
CW197 - Polar Upright Gastro Display Fridge 600Ltr	51	AD346	Handle
CW197 - Polar Upright Gastro Display Fridge 600Ltr	N/A	AB971	Thermostat Protective Box
CW197 - Polar Upright Gastro Display Fridge 600Ltr	N/A	AJ162	Electrics for Compressor HPKD190A
CW197 - Polar Upright Gastro Display Fridge 600Ltr	N/A	AC988	Adjustable Feet (Optional)