




Parts Description of Electric Coffee Maker

Model: DK100

Machine	Code	Description	Stocked Line
F132	T255	Coffee Filter	✓
F132	T254	Water Pipe Module	✓
F132	N812	Drop Collector	✓
F132	N811	Lid	✓
F132	N810	Skidproof Foot	✓
F132	N809	Water Level Tube	✓
F132	N808	Power Switch	✓
F132	N806	Complete Water Faucet	✓
F132	n/a	Bottom Base	n/a
F132	n/a	Bottom Plate	n/a
F132	n/a	Cord Buckle	n/a
F132	n/a	Decorating Button	n/a
F132	n/a	Decorating Cap	n/a
F132	n/a	Eye-Shaped Decorating Piece	n/a
F132	n/a	Heater Windtight Washer	n/a
F132	n/a	Heater Wingtight Washer B	n/a
F132	n/a	Heating Plate Nut	n/a
F132	n/a	Heating Plate Nut	n/a
F132	n/a	Holder	n/a
F132	n/a	Indicating Tube	n/a
F132	n/a	Inner Lid	n/a
F132	n/a	Inner Pot	n/a
F132	n/a	Keep Warm Heater	n/a
F132	n/a	Lamp Housing	n/a
F132	n/a	Lamp Module	n/a
F132	n/a	Level Indicator	n/a
F132	n/a	Middle Ring	n/a
F132	n/a	Power Cord	n/a
F132	n/a	Protective Thermostat	n/a
F132	n/a	Reset Housing	n/a
F132	n/a	Shell Holding Piece	n/a
F132	n/a	Supporting Plate	n/a
F132	n/a	Terminal Block	n/a
F132	n/a	Thermostat Holder	n/a
F132	n/a	U-Shaped Decorating Piece	n/a
F132	n/a	Water Tube Holder B	n/a
F132	n/a	Water Tube Holder A	n/a
F132	n/a	Wind tight Ring	n/a
F132	n/a	Working Thermostat	n/a